

VHC-102 Car Call Security

Setting codes		
1	Activate Independent Service	<i>Car must be stopped at a floor before proceeding to the next step.</i>
2	Press and hold DOOR OPEN	<i>Releasing DOOR OPEN at this point restores normal Independent Service.</i>
3	Press and release a car call button	<i>The button for the selected floor flickers at 1-second intervals for confirmation.</i>
4	Release DOOR OPEN	<i>The button for the selected floor now flashes quickly to indicate that it's ready to receive a new security code.</i>
5	Enter new 4-digit security code <i>Each button press should be distinct and deliberately sustained for at least half a second to ensure recognition.</i>	<i>Use car call buttons to enter the new security code.</i> <i>After the 4th digit is entered, the floor's button will increase its flash rate for 2 seconds and then extinguish to confirm acceptance of the new security code.</i>
	Cancel entry	<i>During this code entry step, if 10 seconds pass without pressing a car call button, or DOOR OPEN is briefly pressed, the selected floor's button will stop flashing and its security code will remain unchanged.</i>
	Clear security code	<i>If DOOR OPEN is pressed and held for 2 seconds during the code entry step, the floor's button stops flashing and security is removed for that floor.</i>
6	Exit Independent Service	<i>Whenever the car is ready to return to automatic operation.</i>

Using codes		
1	Place a car call	<i>If the destination is secure, its button will flash and pre-existing car call lamps will be extinguished temporarily.</i>
2	Enter the 4-digit security code <i>Each button press should be distinct and deliberately sustained for at least half a second to ensure recognition.</i> <i>The code entry sequence may be restarted at any time during the 10 second code-entry period.</i>	<i>Use car call buttons to enter the security code for the selected floor.</i> <i>A correct code entry will increase the flash rate of the selected floor for 2 seconds to confirm acceptance. Pre-existing car calls will then be illuminated along with the new call.</i> <i>If the correct code sequence is not entered within 10 seconds, flashing will stop, and for the next 2 seconds car call buttons will be ignored. Pre-existing car calls will then be illuminated.</i>

**Car Call Security will be disabled during Phase II of Fire Service and EMT/Code-Blue operations. Car Call Security will be disabled when the Security Override switch (OCS input) is active. To view security codes for each floor, navigate to the following menu page on the controller:
MAIN MENU > SETUP > FEATURES > CALL SECURITY > VIEW CODES**